



Maximize your vaping experience with our V3 Air! Flowermate's premier line of Convection Airflow System (CAS) multi-use vaporizers. Featuring Isolated Air Path technology for pure vaping and an advanced ceramic heating chamber with modular temperature range for herbs, waxy and oil.

Designed in California, USA
Assembled in China
Patent Pending

For more product information, visit us online at www.flowermateusa.com
Flowermate Technology, LLC

What's in the Box

- 1 V3.0 Air Vaporizer
- 1 V3.0 Air Borosilicate Glass Mouthpiece
- 1 Liquid/Waxy Chamber(Organic Cotton)
- 1 Medium Stainless Steel Pod
- 1 Water Pipe Adapter
- 3 Stainless Steel Screens
- 1 Packing Tool and Dabber
- 1 Cleaning Brush
- 1 AC/DC to USB Charging Cable
- 1 Warranty and Certificate of Authenticity
- 1 User Manual

1

Key Features

- Patented Convection AirFlow System (CAS). The air flow passes through the top of the chamber instead of the bottom.
- Fully Isolated Air Path allows for clean and pure vaping.
- Advanced Ceramic Heating Chamber.
- Soft Touch Grip.
- Sleek, compact elegant design.
- Exceptional quality made only with medical grade materials.
- Borosilicate Glass Mouthpiece.

Thank you for making Flowermate Technology your premier brand of choice for exceptionally designed Convection AirFlow System (CAS), multi-use vaporizers. Please read this manual carefully before using your V3 Air Dry Herb Vaporizer.

2

What's in a V3 Air?

3

Product Configuration

- A. Power Button** - Power On and Off V3 Air/ 3 range temperature control button.
- B. Mouthpiece** - Borosilicate glass, ergonomically designed.
- C. Ceramic Heating Chamber** - thoroughly and evenly heats your blend.
- D. Chamber Connector** - holds mouthpiece firmly in place.
- E. Medium Stainless Steel Pod** - pack your choice blend for present or on the go vaping (best paired with our Load'X Grinder and Loader - sold separately).
- F. Liquid/Waxy Chamber** - fill your choice oil/waxy (not at the same time).
- G. Charging Port** - AC/DC to USB charging port.

4

How to Use V3 Air with Dry Herbs


LOAD

- Unscrew chamber connector from V3 Air.
- **To vape without Medium Stainless Steel Pods:** Load choice blend loosely into the ceramic heating chamber. Tamp down with the dabber tool. Do not over-fill. (note: do not turn on device while loading blend).
- **To vape with Medium Stainless Steel Pods:** Unscrew pod lid and loosely fill your choice blend into the pod (Recommended to use our patented Load'X Grinder & Loader for mess free grinding and loading). Tamp down with the dabber tool. Do not over-fill. Close pod lid. Insert pod into ceramic heating chamber (note: do not turn on device while loading pods).
- Attach V3 Air chamber connector.

For on-the-go vaping, extra pods along with Load'X Grinder & Loader (sold separately) can be pre-filled for later use.

5

Load'X (Sold Separately) dry herb grinder loader



Introduction:

Maximize your vaping experience with our Load'X Dry Herb Grinder and Loader! Flowermate's uniquely patent pending design was created as the perfect accessory to grind and load your herbs, mess free into the stainless steel pods.

- Mess free grinding and loading.
- Compact design for on the go use.
- Transparent design to see your blend.
- Can Load 2 different sized pods.
- Convenient and easy to use.

More info, please refer to our Load'X user manual.

6

How to Use continued

ACTIVATE

- Rapidly press Power button 5 times within 2 seconds to power on V3 Air. The LED light will flash BLUE to indicate power on and the heating chamber activated
- Let V3 Air sit as it heats to desired temperature setting. The LED light will stop flashing and become solid BLUE, indicating that the device is ready to use. Press and hold power button for 2 seconds to advance to the next temperature level (see temperature color guide below).
- To Power Off V3 Air, rapidly press power button 5 times within 2 seconds.

Temperature Color Indicators:

- Blue: 385°F (196°C)
- Purple: 400°F (204°C)
- Red: 415°F (213°C)


SAVOR

- To Vape: Inhale slowly through mouthpiece and enjoy your blend.

7

How to Use V3 Air with oil/waxy

LOAD



Oil

- Fill oil/waxy chamber with at least 5 drops of (0.2 - 0.3ml) oil. Let oil settle for a few seconds.
- Insert oil/waxy chamber into ceramic heating chamber (note: do not turn on device while loading oil/waxy chamber).



Waxy

- Place concentrated oil around the recess of the lid. Screw lid on to oil/waxy chamber.
- Insert oil/waxy chamber, with lid facing down towards ceramic heating chamber (note: do not turn on device while loading oil/waxy chamber).

8

Technical Specifications

V3 Air

- Dimensions: 6.14" H x 0.94" D x 0.94" W (156mmH x 24mmD x 24mmW)
- Capacity: 1300mAh High-drain Battery
- Rated Voltage: 3.7V
- Power On/Off: Press power button 5 times consecutively
- Safety Power Duration: 5 minutes
- Battery Low Indicator: LED flashes 6 times rapidly

9

Cleaning and Maintenance

The mouthpiece of the V3 Air may become clogged when used for an extended amount of time; resulting in difficult draw resistance or less vapor being released. Use the following guidelines to clean and maintain your device:

- **Ceramic Heating Chamber:** Use the brush tool to gently clean the walls of the heating chamber.
- **Ceramic Filter:** Use a fine paperclip or pin and gently insert between the holes. Push through thoroughly to clear the airway then wipe clean with a lint free cloth.
- **Mouthpiece:** carefully remove glass mouthpiece from device, wash gently with warm water, rinse and air dry. For stubborn stains, rub gently with a damp cotton swab.

Tips

For best results, do not over-pack the ceramic heating chamber with your product. Over-packing will cause constricted air flow and uneven vaping.

After filling, use the packing tool to gently stir and aerate the product to ensure vapor is released.

Always properly prepare the device before use to reduce blockage of the mouthpiece.

Take the mess out of grinding and loading your blend with our Load'X Grinder and Loader. Sold separately.

10

Battery and Charging

CHARGING

- Initially charge the V3 Air for 1 to 1.5 hours. While charging, the LED light will be red. The battery will stop charging and the LED light turns green.
- Low battery level is indicated by the LED light flashing red 6 times consecutively. Charge battery with included AC/DC to USB wall charger.
- Do not use V3 Air while charging. This will cause damage to the device.
- To prevent the device from overheating, do not leave the charger plugged in overnight.
- Do not leave charger plugged in or unattended without the device. Do not charge unit on bare carpet or rug.

BATTERY

The device contains a Lithium-Ion battery. Take caution and dispose in the correct receptacle. Do not discard in trash. Do not over charge. Do not short circuit the battery.

Notice: Lithium Ion Batteries are subject to degradation and reduced run time over the course of regular use at over 200°F; while Flowermate took great care in selecting premium quality long life Lithium Ion batteries due to their non-memory features and ability to cycle 300 times preceding degradation, battery life will gradually diminish with extended use.

11

Safety

WARNING

Failure to follow these safety instructions could result in personal injury or damage. Users of this device do so at their own risk. Neither Flowermate Technology, LLC nor its retailers assume any responsibility or liability associated with the use/misuse of the device. Flowermate Technology branded products are intended for adult use and consumption only. Keep this booklet in a safe place for future reference.

DISCLAIMER

This device is designed as a mobile solution for the practitioners of aromatherapy and should be used for dry herbal blends as indicated. This device is not intended for use with illegal substances.

CHOKING HAZARD

The V3 Air contains small parts which may be a choking hazard to small children. Keep device away from children.

12

Safety continued

HANDLING

- Do not drop, deform, bend, crush, puncture, incinerate, microwave, shred, paint or insert foreign objects into a Flowermate Technology, LLC V3 Air.
- Do not clean V3 Air other than instructed by Flowermate Technology, LLC.
- Do not attempt to repair or modify V3 Air yourself.
- Do not use a damaged V3 Air charger or non Flowermate Technology charger. Incompatible chargers may carry different voltage, which may be a fire hazard. Use only the charger provided. Failure to do so will void the limited warranty offered on Flowermate Technology products.
- Use caution when handling V3 Air, the heating chamber area is hot when the device is powered on. Refrain from direct contact with the main heating chamber when hot. Do not leave the device unattended when it is powered on or while the device is still hot.

13

Safety Features

SLEEP PROTECTION

The device is equipped with a safety sleep mode. When the device is powered on and there is no operation for over 5 minutes, it will go into sleep mode. Press and hold the power button for 2-3 seconds to resume vaping.

MEMORY FUNCTION

The device features a smart memory function. It will memorize the data of current use before powering off. When powered on for next use, the last setting will be displayed.

SMART TEMPERATURE LEVELS

The V3 Air is equipped with a smart function to shift between 3 temperature level settings by pressing and holding the power button for 2 seconds.

CONVECTION AIRFLOW SYSTEM (CAS)

Patented technology exclusively by Flowermate Technology, LLC. The airflow is directed evenly from the top of the chamber instead of the bottom. Distributing the air throughout the chamber at the same rate without burning the blend. Look for this symbol to indicate a true CAS product.



14

Warranty

1 YEAR LIMITED WARRANTY

Flowermate Technology, LLC warrants this Flowermate Technology, LLC branded device against defects in materials and workmanship under normal use for a period of one (1) year from the date of retail purchase by the original end-user. The original bill of sale is required to redeem warranty. The limited warranty covers one (1) year for electronics, ceramic heating chamber, structural integrity and attachments. The Lithium-Ion battery ninety (90) days. If a physical defect arises and a claim is made within the Warranty Period, at its option and to the extent permitted by law, Flowermate Technology will either:

- repair the product defect
- exchange the product with a product warranty that is new or functionally equivalent device or
- refund the purchase price of the device.

15

Warranty continued


EXCLUSIONS & LIMITATIONS

The Limited Warranty applies only to products manufactured by Flowermate Technology, LLC, which can be identified by the "Flowermate Technology, LLC" trademark, tradename or logo affixed to the device. The Limited Warranty does not apply to any non-Flowermate Technology, LLC products. This warranty does not apply to (i) damage caused by accident, abuse, misuse, flood, fire, earthquake, acts of piracy or other external causes; (ii) damage caused by operating the product outside the permitted or intended use as described by Flowermate Technology, LLC; (iii) a device or part that has been modified to alter the functionality or capability without the written permission of Flowermate Technology; (iv) cosmetic damage, including but not limited to dents, scratches and/or broken plastic.

This warranty applies to the original end-user and is non-transferrable. Flowermate Technology, LLC warranties only apply to devices that are purchased from authorized retailers serviced by an authorized Flowermate Technology, LLC distributor.

For questions regarding authorized retailers, additional warranty details, please visit:
www.flowermateusa.com

Importeur:
Micropac GmbH
www.micropac.eu

CE  micropac.eu

16

THE CROWN